




Intallation steps




Step 1
Open the panel by rotating a
quarter with the screwdriver




Step 2
Cut off power supply ,connect the
wires and tighten screws



Step 3
Fix with two screws with
appropriate strength



Step 4
Cover the panel and
connect the power





Ultra-thin PC Switches Sockets



Ultra-thin



PC material



Flame retardant



T10 gold



T11 ash




T13 white



T15 blue



T16 black



T17 silver

T10 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch



1gang15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



3 pin MF socket



1 gang 3 pin MF socket
with neon+2USB




25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed




Adjust speed




2 pin socket



1 gang 3 pin MF socket+
USB+Type C



1 gang with 4 pins socket



2 gang with 4 pins socket



USB+Type C



Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket




1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket with neon



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

T11 SERIES




1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch




1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

TV+TEL socket
TV+computer socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

1 gang with 4 pins socket

3 pin MF socket

USB+Type C



4 pins socket

1 gang 3 pin MF socket+
USB+Type C

1 gang 3 pin MF socket
with neon

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



2 gang with 4 pins socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket with neon

T12 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch




1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon




1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed




Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C



Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 3 pin MF socket+
USB+Type C



1 gang 3 pin MF socket




1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket with neon



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

T13 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch




Doorbell switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



3 pin MF socket




1 gang 3 pin MF socket
with neon+2USB




2 pin socket



1 gang 3 pin MF socket+
USB+Type C



1 gang with 4 pins socket



2 gang with 4 pins socket



USB+Type C



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate



Blank plate(3*6)




Big panel 4gang



Big panel 6gang




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket with neon

T15 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch




Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

2 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

1 gang with 4 pins socket

3 pin MF socket

USB+Type C



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socke

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket with neon



TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket

T16 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

2 gang with 4 pins socket

3 pin MF socket

USB+Type C



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socke

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket with neon

T17 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed




Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket with neon



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

European style PC large board Switch and socket series



Anti-fingerprint



PC material



Flame retardant



B20 gold



B21 ash




B22 pearl white




Big Panel PC Switches Sockets




G10 black



G70 white



G80 gold



G90 ash



PC material



Flame retardant

G10 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket




USB+Type C



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket with neon



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket




2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

G70 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

2 gang with 4 pins socket

3 pin MF socket

USB+Type C




4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socke

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C




TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch




25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket with neon

G80 SERIES


LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch




4 gang 1 way switch
4 gang 2 way switch



Doorbell switch




Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch



1gang 15A



1 gang 3 pin MF socket
with neon




1 gang 15A socket with
neon




1 gang with 2 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch




1gang + dimmer



1 gang+Adjust speed




Adjust speed




2 pin socket




1 gang 3 pin MF socket+
USB+Type C




1 gang with 4 pins socket




3 pin MF socket



USB+Type C



Blank plate



Blank plate(3*6)




Big panel 4gang




Big panel 6gang



4 pins socket




1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket




2 gang with 4 pins socket




TV socket




2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV+TEL socket
TV+computer socket



TEL socket
Computer socket

G90 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch




Doorbell switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 2 pins socket




1 gang 3 pin MF socket
with neon+2USB




2 pin socket




1 gang 3 pin MF socket+
USB+Type C



1 gang with 4 pins socket



3 pin MF socket



USB+Type C




4 pins socket



1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socket




1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket



2 gang with 4 pins socket




2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int




5 pin MF socket




TV socket



TEL socket
Computer socket



Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch




25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



Ultra-thin matte acrylic Switches Sockets



Ultra-thin



Acrylic



Anti-fingerprint



PC material




Flame retardant



T51 ash



T51 ash



T56 black

T51 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



1 gang 3 pin MF socket+
USB+Type C




1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon




1 gang 3 pin MF socket
with neon+2USB



3 pin MF socket



USB+Type C



Satellite socket



TV+TEL socket
TV+computer socket



1 gang with 4 pins socket



2 gang with 4 pins socket



1gang 15A



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 pin socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang



2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket

T52 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch




1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang 3 pin MF socket
with neon+2USB

1 gang 3 pin MF socket
with neon+2USB




25A DP switch
45A DP switch

Dimming

1gang + dimmer

1 gang+Adjust speed

Adjust speed




2 pin socket

1 gang 3 pin MF socket+
USB+Type C

TV+TEL socket
TV+computer socket

TEL socket
3 pin MF socket

USB+Type C



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socket

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket



1 gang with 4 pins socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



2 gang with 4 pins socket

TV socket

T56 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



TV socket



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



TEL socket
Computer socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



Dimming



1gang + dimmer



1 gang+Adjust speed



Adjust speed



TV+TEL socket
TV+computer socket



1 gang 3 pin MF socket+
USB+Type C



13A socket



3 pin MF socket



USB+Type C



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang



1gang 15A



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



2 pin socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket





4 pins socket




1 gang with 4 pins socket



2 gang with 4 pins socket



Q9 white



Q10 gold



PC material



Flame retardant

Q9 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch




TEL socket
Computer socket



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



TV+TEL socket
TV+computer socket



1 gang 3 pin MF socket
with neon+2USB



Voice switch



Dimming




1gang + dimmer



1 gang+Adjust speed



Adjust speed




TV socket



1 gang 3 pin MF socket+
USB+Type C




TEL+computer socket
Double TEL socket
Double computer socket




3 pin MF socket




USB+Type C




European socket




Schuko socket




25A DP switch
45A DP switch




25A DP switch
45A DP switch




Human body induction




1gang 15A



1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socket




1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C




Blank plate



Blank plate(3*6)




Big panel 4gang



Big panel 6gang
2 gang 3 pin MF socket




2 pin socket



1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int




5 pin MF socket





2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon



4 pins socket



1 gang with 4 pins socket



2 gang with 4 pins socket

Q10 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch




1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

3 pin MF socket

1 gang 3 pin MF socket
with neon+2USB




2 pin socket

1 gang 3 pin MF socket+
USB+Type C

Double TV socket

TV+TEL socket
TV+computer socket

USB+Type C




TV socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socket

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C




TEL socket
Computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



4 pins socket

1 gang with 4 pins socket

2 gang with 4 pins socket




Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

Dimming

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket



S40 gold

S40 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



3 pin MF socket



1 gang 3 pin MF socket
with neon+2USB



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



TV+TEL socket
TV+computer socket



TEL socket
Computer socket



USB+Type C



4 pins socket



1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socke



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



1 gang with 4 pins socket



1 gang with 2 pins socket




2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



2 gang with 4 pins socket



TV socket



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch



Dimming



1gang + dimmer



1 gang+Adjust speed



Adjust speed




Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket

S50 SERIES


LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch




4 gang 1 way switch
4 gang 2 way switch




Doorbell switch




Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket



45A DP switch




25A DP switch




Touch switch



1gang 15A




1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon




4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



Dimming




1gang + dimmer



1 gang+Adjust speed



Adjust speed




2 pin socket




1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket




USB+Type C




Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang




1 gang with 4 pins socket



1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socket




1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket




TV+TEL socket
TV+computer socket




1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket



Q5 gold



Q6 white



PC material



Flame retardant



Q5 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch



Touch switch




1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket




1 gang 3 pin MF socket
with neon+2USB



Blank plate



Dimming



1gang + dimmer



1 gang+Adjust speed



Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



TV+TEL socket
TV+computer socket




3 pin MF socket




USB+Type C




25A DP switch
45A DP switch




Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



2 gang with 4 pins socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

Q6 SERIES



LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch




1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

3 pin MF socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

1 gang with 4 pins socket

2 gang with 4 pins socket

USB+Type C



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socket

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed




Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket
with neon

Q7 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

TV+TEL socket
TV+computer socket

3 pin MF socket

USB+Type C



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socket

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



TEL socket
Computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



2 gang with 4 pins socket

TV socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed




Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket



H20 gold



H20 gold



H21 ash

H20 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

TV+TEL socket
TV+computer socket

3 pin MF socket

USB+Type C



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socke

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



2 gang with 4 pins socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket

H21 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket




TV socket




TEL socket
Computer socket




H11 gold



H13 ash



H14 white



H14 white

H11 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch




1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



2 pin socket

1 gang 3 pin MF socket+
USB+Type C

2 gang with 4 pins socket

3 pin MF socket

USB+Type C




4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socket

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV


2 pin socket with TEL
2 pin socket with Int

5 pin MF socket



TV socket

TEL socket
Computer socket




Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed



Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang



2 gang 3 pin MF socket with neon

2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket

H13 SERIES




1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch




4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch




1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate




Blank plate(3*6)



Big panel 4gang




Big panel 6gang



2 gang with 4 pins socket



1 gang 3 pin MF socket+
USB+Type C




13A socket



3 pin MF socket



USB+Type C



4 pins socket




1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon




2 gang 3 pin MF socket




TV+TEL socket
TV+computer socket



1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int



5 pin MF socket




TV socket



TEL socket
Computer socket

H14 SERIES



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch




1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch




1gang + dimmer



1 gang+Adjust speed




Adjust speed




2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C




Blank plate




Blank plate(3*6)



Big panel 4gang



Big panel 6gang




4 pins socket




1 gang 13A socket
with neon+USB+Type C




1 gang 3 pin MF socket




1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int




5 pin MF socket



TV socket




TEL socket
Computer socket



G50 ash



G50 ash



G60 gold

G50 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

G60 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch



1gang 15A

1 gang 3 pin MF socket
with neon

1 gang 15A socket with
neon

1 gang with 4 pins socket

1 gang 3 pin MF socket
with neon+2USB



5 pin MF socket

1 gang 3 pin MF socket+
USB+Type C

2 gang with 4 pins socket

3 pin MF socket

USB+Type C



4 pins socket

1 gang 13A socket
with neon+USB+Type C

1 gang 3 pin MF socke

1 gang 5 pin MF socket
with neon

3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket

2 pin socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int



TV socket

TEL socket
Computer socket



Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch



25A DP switch
45A DP switch

25A DP switch
45A DP switch

1gang + dimmer

1 gang+Adjust speed

Adjust speed




Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang




2 gang 3 pin MF socket with neon


2 gang 3 pin MF socket with neon+2USB

2 gang 3 pin MF socket+USB+Type C
with neon

2 gang 3 pin MF socket



G20 gold




G20 gold



G30 ash

G20 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION




1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch




1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket




1 gang 3 pin MF socket
with neon+2USB



5 pin MF socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket




USB+Type C



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon




3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket



2 pin socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



TV socket



TEL socket
Computer socket



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch



25A DP switch
45A DP switch




1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate




Blank plate(3*6)




Big panel 4gang




Big panel 6gang




2 gang 3 pin MF socket with neon



2 gang 3 pin MF socket with neon+2USB



2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket

G30 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch



2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



1gang 15A



1 gang 3 pin MF socket
with neon



1 gang 15A socket with
neon



1 gang with 4 pins socket



1 gang 3 pin MF socket
with neon+2USB



2 pin socket



1 gang 3 pin MF socket+
USB+Type C



2 gang with 4 pins socket



3 pin MF socket



USB+Type C



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket



45A DP switch



25A DP switch



Touch switch



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1gang + dimmer



1 gang+Adjust speed



Adjust speed



Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang




2 gang 3 pin MF socket with neon




2 gang 3 pin MF socket with neon+2USB




2 gang 3 pin MF socket+USB+Type C
with neon



2 gang 3 pin MF socket



S16 whiet




S60 gold



S70 ash

S16 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch




25A DP switch




Touch switch




1gang 15A



1 gang 3 pin MF socket




1 gang 15A socket




1 gang with 4 pins socket



1 gang 3 pin MF socket
+2USB



25A DP switch
45A DP switch




25A DP switch
45A DP switch




1gang + dimmer




1 gang+Adjust speed



Adjust speed




2 pin socket



1 gang 3 pin MF socket+
USB+Type C




2 gang with 4 pins socket




3 pin MF socket




USB+Type C




Blank plate



Blank plate(3*6)



Big panel 4gang




Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket




1 gang 5 pin MF socket



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket




2 gang 3 pin MF socket+2USB



2 gang 3 pin MF socket+USB+Type C




2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int



5 pin MF socket




TV socket




TEL socket
Computer socket

S60 SERIES


LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch




4 gang 1 way switch
4 gang 2 way switch



Doorbell switch




Satellite+TV socket




Satellite+TEL socket
Satellite+computer socket




45A DP switch




25A DP switch




Touch switch




1gang 15A




1 gang 3 pin MF socket
with neon




1 gang 15A socket with
neon




1 gang with 4 pins socket




1 gang 3 pin MF socket
with neon+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch




1gang + dimmer



1 gang+Adjust speed



Adjust speed




2 pin socket



1 gang 3 pin MF socket+
USB+Type C




2 gang with 4 pins socket



3 pin MF socket



USB+Type C



Blank plate




Blank plate(3*6)




Big panel 4gang



Big panel 6gang



4 pins socket



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket
with neon



3 pin MF socket+2USB
+Type C



2 gang 3 pin MF socket with
neon




2 gang 3 pin MF socket with
neon+2USB



2 gang 3 pin MF socket+USB+
Type C with neon




2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket

S70 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch




1gang 15A



1 gang 3 pin MF socket
with neon+USB+Type C



1 gang 15A socket




1 gang with 4 pins socket



3 gang 3 pin MF socket
+2USB+Type C



25A DP switch
45A DP switch



25A DP switch
45A DP switch



1 gang+Adjust speed



Adjust speed



2 pin socket




2 gang with 4 pins socket



4 pins socket



1 gang 5 pin MF socket



TV+TEL socket
TV+computer socket



1 gang with 2 pins socket



2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket




Blank plate



Blank plate(3*6)



Big panel 4gang



Big panel 6gang




2 gang 3 pin MF socket



2 gang 3 pin MF socket+2USB



2 gang 3 pin MF socket+USB+Type C



TV socket



TEL socket
Computer socket